


koło



WHCN 0802 1000	==	80	30	40	200	12	nie dotyczy
WHCN 1002 1000	==	100	30	40	250	12	nie dotyczy
WHCN 1252 1000	==	125	35	50	250	15	nie dotyczy
WHCN 1403 1000	==	140	35	50	300	15	nie dotyczy
WHCN 1603 1000	==	160	40	58	400	20	nie dotyczy
WHCN 1803 1000	==	180	45	58	450	20	nie dotyczy
WHCN 2003 1000	==	200	50	58	600	20	nie dotyczy

na płytce



JLCN 0802 1000	BLCN 0802 1000	FLCN 0802 1000	==	80	100x85	80x60	8,5x12	108	37	100
JLCN 1002 1000	BLCN 1002 1000	FLCN 1002 1000	==	100	100x85	80x60	8,5x12	128	37	120
JLCN 1252 1000	BLCN 1252 1000	FLCN 1252 1000	==	125	100x85	80x60	8,5x12	155	42	170
JLCN 1253 1000	BLCN 1253 1000	FLCN 1253 1000	==	125	140x110	105x80	11x16	155	42	170
JLCN 1402 1000	BLCN 1402 1000	FLCN 1402 1000	==	140	100x85	80x60	8,5x12	176	45	200
JLCN 1403 1000	BLCN 1403 1000	FLCN 1403 1000	==	140	140x110	105x80	11x16	176	45	200
JLCN 1603 1000	BLCN 1603 1000	FLCN 1603 1000	==	160	140x110	105x80	11x16	197	55	300
JLCN 1803 1000	BLCN 1803 1000	FLCN 1803 1000	==	180	140x110	105x80	11x16	225	55	300
JLCN 2003 1000	BLCN 2003 1000	FLCN 2003 1000	==	200	140x110	105x80	11x16	235	55	300